

# ETA PU PelletsUnit 7, 11 und 15 kW

## Kurzbedienungsanleitung (Details siehe Bedienungsanleitung)

The control panel features a central display with a house icon showing room temperature (Raum 22,5°C) and heating temperature (Heiz 43°C). Below the display is a 24-hour clock with icons for different heating phases. The top navigation bar includes buttons for Kessel, PU, Warmwasser, HK1, HK2, Lager, and Sys. The left side has a vertical menu with icons for customer overview, expert functions, error messages, expert functions, and info.

**Ein Tag**

**Kessel** | **PU** | **Warmwasser** | **HK1** | **HK2** | **Lager** | **Sys**

**Puffer** | **Warmwasser- bzw. Boiler** | **Boilertemperatur einstellen** | **Heizkreis 1** | **Heizkreis 2** | **Lagermenge / Liefermenge eintragen** | **System**

**Ein Tag**

Raum 22,5°C  
Heiz 43°C

Aussen -12°C

0 2 4 6 8 10 12 14 15 18 20 22

Do 28.12, 06:35:20

**Heizkreis Ein / Aus**  
rot = Sommerbetrieb  
grün = Winterbetrieb

**permanenter Heizbetrieb**

**"Kommen"**  
kurzfristige, manuelle Heizphase

**"Gehen"**  
kurzfristige, manuelle Absenkung

**Automatikbetrieb**  
(Normalbetrieb)

**Einstellen der Heizzeiten**  
durch Antippen erscheint die Wochenschaltuhr zum Einstellen der Heizzeiten

**permanente Absenkung**  
"Urlaub" Absenkphase bis zum gewählten Datum

**Vorlauftemperatur des Heizkreises**  
Veränderung Raumtemperatur +/- 5°C

**Kundenübersicht**

**für den Fachmann**

**für den Fachmann**

**für den Fachmann**

**Fehlermeldungen**

**für den Fachmann**

**INFO**

gelb eingefärbte Bedienfelder / Funktionen nur sichtbar, wenn aktiv bzw. konfiguriert